



- NOTE:
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm).
 3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
 4. Ø 3/16" (5mm) PILOT HOLE TO BE DRILLED AT INSTALLATION.

HDG. _____ DR. _____

RESPONSIBILITY
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE
 WOOD DOOR
 03 WS
 CYLINDER ESCUTCHEON TRIM
 FOR 10, 20, 21 SERIES



DO NOT SCALE DRAWING

DATE 6/21/05

TEMPLATE NUMBER T1041